




# DUO-SAFETY LADDER CORPORATION

## Ladder Lock Assembly




### Duo-Safety Spring Lock Assembly

1. Lock housing & cover plate (not shown)
2. Lock hook
3. Finger (note position)
4. Spring
5. Mounting bolt holes
6. Shoulder bolt hole

All ladder lock assemblies are a two piece aluminum assembly consisting of:

1. Lock housing (base plate with mounting bolt holes and cover plate with rung mount.
2. Lock hook - solid aluminum hooks that engage rungs.
3. Finger - solid aluminum finger - depress the hook to allow disengagement of the rung.
4. Spring - stainless steel torsion spring- provides automatic action to assembly.
5. Shoulder bolts & nuts, 3 each shoulder bolts & nuts hold the parts in place and hold the cover plate over the base plate.



Lettered Set A/B Pictured

**Note: Base plate assemblies are all the same.**

Cover plate assembly includes a welded aluminum tube piece that accepts the lock rung and rivets. Cover plates are made in 2 different versions.

**A/B Pair** (Right & left) used on series 500/525, 1000, 900/925, 1500/1525, YGE-2/YGE-3

**C/D Pair** (Right & left) used on 1200/1225

Replacement lock assemblies are sold in pairs only and include instructions and all mounting fasteners. Normally you will reuse the old lock rung from the old lock assemblies. However, if damaged, you must also order a replacement rung. Please follow the replacement instructions provided with the replacement locks for proper installation.

Be sure to advise proper lock assembly version/lettered pair required to ensure proper fit.

DUO-SAFETY LADDER CORPORATION 513 W 9th Avenue PO Box 497 Oshkosh WI 54903-0497

Toll Free: 877-386-5377

Fax: 920-231-2460

mail@duosafety.com

www.duosafety.com



# DUO-SAFETY LADDER CORPORATION

## Ladder Lock Assembly

### LOCK HOUSING REPAIR KIT - NEW ALUMINUM LOCKS

Includes all the parts needed to repair a set (2) of our new aluminum locks.

#### Parts in kit:

- 6 ea. Shoulder bolts
- 4 ea. Large plastic washers
- 4 ea. Small plastic washers
- 2 ea. Lock springs
- 6 ea. 1/4" x 20 hex head lock nuts
- 4 ea. 1/4" x 20 x 3/4" hex head bolts
- 4 ea. 1/4" x 20 regular hex head nuts
- 4 ea. 1/4" lock washers
- 4 ea. 1/4" flat washers
- 4 ea. Stainless steel pop rivets

